


Mini Pocket Printer User Manual

ios Android

APP downloads

Search“**Luck Jingle**” in the App Store

Name:	Mini Pocket Printer
Model:	A2
Size:	90x88x42mm
Weight:	140g
Input:	5V ⎓ 1A
Connector:	USB-C
Battery capacity:	1200mAh(3.7V)
Consumable items:	57x30mm
Print:	Temperature-sensitive

EN

Product introduction

Power button Long press for 3 seconds to turn on/off



Power indicator status

Green light always on: fully charged; Power on and in normal condition;
Green light flashing: power on for charging;
Red light constantly on: abnormal state (paper shortage, lid opening, overheating, low power);
Red light flashing: power off and charge;
Blue light: The power on status is normal and Bluetooth has been connected;

In the startup state, click the power button six times to calibrate the label.

⚠ Please avoid direct contact with the print head to avoid damage, especially after printing, do not directly touch the print head immediately to prevent overheating

APP downloads and warnings

Mobile Download

Search“**Luck Jingle**” in the App Store

Download on the **App Store**


Get it on **Google Play**

ios Android

Warnings

- This product is a professional product, please use the original type of battery, if you replace theoriginal type of battery or use the wrong type of battery, there will be explosion risk, be sure to follow the instructions to dispose of the used battery.
- Only one side of the printing paper can be printed. Please place the printing paper in the correct direction.

Replacement of consumables



1. Open the cover: see the direction of the arrow as shown in the figure.and pull the paper compartment cover up to open the cover.
2. Consumables:as the arrow shown , put the heat sensitive surface of the paper on the same side as the thermal print head

Safety and precautions

1. There is a built-in lithium battery, please do not use it in the environment with temperature higher than 40 ℃ ; keep away from fire and other heat sources, and do not place it in the hot sun, such as closed car;
2. Children should be charged and used under the supervision of adults.After full charge, please make sure to pull out the charging line in time to prevent overheating, short circuit or fire;
3. Do not put the product in fire or water to avoid battery short circuit or fire or burn;

FCC Statement

1.This device complies with Part 15 of the FCC Rules. Operation is subject to thefollowing two conditions:
(1)This device may not cause harmful interference.
(2)This device must accept any interference received, including interference that may cause undesired operation
2. Changes or modifications not expressly approved by the party responsible forcompliance could void the user's authority to operate the equipment.Note:This equipment has been tested and found to comply with the limits for a class Bdigital device,pursuant to Part 15 of the FCC Rules. These limits are designed to providereasonable protection against harmful interference in a residential installation.
This equipment generates uses and can radiate radio frequency energy and,inot installed and used in accordance with the instructions,mayharmfucauseinterference to radio communications.However,there is no guarantee that interferenceWll not occur ina particular installationif this eauipmemt does cause harmfuinterference to radio or television reception,which can be determined by turning theequipment off and on,the user is encouraged to try to correct the interference by one ormore of the following measures.
· Reorientor relocate the receivina antenna.
· Increase the separation between the equipment and receiver.
· Connect the equipment into an outlet on a circuit different from that to which thereceiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement
The device can be used in portable exposure condition without restriction.

www.luckjingle.com

Made in China